

INSTALLATION INSTRUCTION

※ ACCESSORIES CHECKING

LIST OF THE STANDARD ACCESSORIES:


Please double-check the accessory list herein after and contact our company or our distributor for any un conformity.

Remarks:

1. Without affecting their performance, accessories may be changed without further notice;



2. Drawings for reference only, product size & shape refer to actual.

Accessories list		
No.	Name	Qty
1	Main body	1
2	Weight	1
3	Rubber flat mat	1
4	Inlet hose	2







※ Installation Instructions

- ★ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ★ To avoid the faucet from jamming, do flush the water pipe before installation;
- ★ After installation, make sure every joint safely sealed & no leaking;
- ★ Using condition: Working pressure at 0.05-1.0MPa(including cold & hot water pressure), with applicable water temperature: 4°C-90°C;
- ★ Make sure to connect the hot/cold inlet pipe correctly, if standing in front, hot water pipe connecting to the left & cold water pipe connecting to the right.




※ Installation Procedures



※ Usage

☆ How to operate the handle

1. Raise the handle up for opening water, push it down for close;
2. Turn the handle to the left to increase hot water flow for higher water temperature, and lower water temperature by operating reversely.



※ Cleaning & Maintenance

☆ To keep the product clean & shining, follow as below:

1. Flush with clean water & dry with soft cloth only;
2. If any dirt, clean with soft liquid or transparent glass detergent;
3. Do not use any scrubbing detergent, polisher, sani-cloth, paper tissue or scraper;
4. Do not use acid detergent, insoluble grain-like detergent or soap;
5. Circumrotate the aerator and clean it when necessary.

